

# SkyWire™

## Configuration Controller

### Installation Procedure

AN215  
Rev. A  
March, 2009



<b>SkyWire™ Configuration Controller Installation</b> <b>AN215 - Record of Revisions</b>
---------------------------------------------------------------------------------------------

Comtech EF Data is constantly improving its products and therefore the information in this document is subject to change without prior notice. Comtech EF Data makes no warranty of any kind with regard to this material, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. No responsibility for any errors or omissions that may pertain to the material herein is assumed. Comtech EF Data makes no commitment to update nor to keep current the information contained in this document. Comtech EF Data assumes no responsibility for use of any circuitry other than the circuitry employed in Comtech EF Data's systems and equipment.

Revision Level	Date	Reason for Change
1.0	03-08-2008	Initial Release
A	3-4-2009	Updated

### Revision Approval


Revision Level	<u>Engineering Approval</u> Printed Name, Date, and Signature	<u>Production Approval</u> Printed Name, Date, and Signature
A		

# SkyWire Configuration Controller Installation Instructions

## Step1

Place the SkyWire Configuration Controller CD-ROM in the CD-ROM Drive and double-click on the SkyWireControllerInstaller jar file.

Read the Radyne license agreement carefully. Click the "I Agree" to proceed with the installation.



## Step2

Review the system requirements and click “Next”. The application will install the Skywire Configuration Controller on your computer.



### Step3

Use the default installation subdirectory or click “Browse” to modify. Press Intall to begin installation.



### Step4

Installation complete. Click “Close” to exit.

